



Essential Inspection Points for Motor Homes

We appreciate your business and look forward to providing you with the most advanced RV inspection available in today's RV market. So that we may provide you with a thorough inspection, your RV will need to be hooked up to all the utilities: fresh water, electricity, and sewer during the inspection.

Due to the nature of RV absorption refrigerators and the time it takes for these refrigerators to cool the refrigerator must have been in operation for at least 12 hours before an accurate temperature reading can be taken in the freezer and the refrigerator compartments.

This report will consist of 25 to 30 photos describing the items that have been identified during the detailed **Essential Motor Home Inspection**.

	In <mark>spect and rate the overall Roof Co</mark> ndition.
	Rate the condition of the roof vents, air conditioners, antenna and other components that are mounted on the roof.
Sid	ew <mark>all and End Cap</mark> s
	Inspect and evaluate the appearance and functional condition of the sidewalls, entrance doors, windows and cargo
	access doors.
Slic	de <mark>Out Rooms</mark>
	Inspect and rate the roof condition.
	Inspect and evaluate the condition of the seals, sweeps and gaskets for possible damage.
Aw	nings and Slide Out Toppers
	Operate and rate condition of the awning frames and latching mechanisms.
Cha	assis Turn Signal and Running Lights (12-volt DC)
	Activate and evaluate the operation of the DOT lights.
	Visually inspect the chassis battery compartment the electrical connections and batteries.
120	O Volt AC Electrical System (house type power)
	Inspect and rate the condition of the power cord and its connection ends.
	Remove cover panel of 120-volt circuit breaker box to visually inspect the condition of the wiring, circuit breakers and grounding connections.
	Test and verify the output operation of the 120 VAC to 12 VDC converter for charging of the deep cycle batteries.
	nerator- Engine – if installed *strongly recommend performing oil analysis to determine internal combustion engine apponent condition.
	Check oil level.
	Start and operate the onboard generator.
_	





det	nerator - Radiator - if installed on this model of Generator *strongly recommend performing coolant analysis to ermine the condition of the coolant fluid and the internal cooling system. Visually inspect the coolant reservoir, radiator, and hoses.
	erter – if installed Identify and note the model and serial number of the inverter. Visually inspect the wiring and electrical connections and fuses/circuit breakers.
	ech Battery System – (12-volt DC deep cycle Battery Electrical System) Evaluate the condition, age, and matched sizing of the battery stack. Access and visually inspect the wiring, fuse panel and fuses of the 12-volt DC electrical system.
	sh Water System Verify the fresh water connections for the City Water hookup are operational. Verify the onboard fresh water tank and pressure pump system will operate and maintain pressure.
	Ste Water Systems – (Gray and Black Water) Operationally test and inspect both waste (gray and black) plumbing systems for leaks under the sinks, shower, around the toilet and discharge lines. Operate both drain valves and test for ease of operation. Verify the drain cap is in place and will hold waste water.
Life	e Safety Items
	Perform and document LP gas timed leak test at cook top burner spud for 5 minutes at 8 inches of water column gas
	Test the Ground Fault Circuit Interrupter (GFCI) circuits in the 6-foot range of the water areas of the bathroom, kitchen and exterior receptacles.
	Test all wall receptacles for correct polarity and ground fault. Test the exterior skin for Hot Skin that would cause electrical shock. Emergency Exit Windows – Verify all safety windows are operational.
	Fire Extinguisher – Verify unit is secure in bracket and dial indicates extinguisher is fully charged. Smoke/Fire Detector –Test and verify operation of units.
	Carbon Monoxide Detector (if applicable) – Test and verify operation of unit. LP Gas Detector – Verify gas detection and audio alarm. Document expiration date of detector. Verify the rubber grommet is properly sealed around LP gas line of water heater – if equipped.
LP (Gas System
	Visually inspect all hoses and pressure regulators for damage and age deterioration. Verify the plastic cover has been installed over the regulator.
ASI	ME tank - if equipped
	Conduct a visual inspection of tank for rust or physical damage if tank is accessible.

Refrigerator





	Identify the brand, model, and type of refrigerator. Operate on all heat sources – 120-volt AC, LP gas and for 3-way refrigerators, 12 volt DC. Collect serial and model number and verify with manufacturer if recall notice has been issued and completed for this unit.
_ _ Fur	ter Heater - if equipped Identify the brand, model, and type of water heater. Fill tank with water (if necessary) and verify operation on all heat sources – LP gas and 120-volt AC if equipped with heating element. nace – if equipped Operate and verify warm air discharge out of vents and proper return air flow to unit.
	ok Top/ Stove Verify the ignition and operation of all top burners and the oven flame (if equipped).
	Conditioner(s) Perform cooling efficiency test (Delta T) on each unit.
	sher/ Dryer Visually inspect and verify a wash and rinse cycle of the washer and dryer. Evaluate and rate the exterior condition of the dryer exhaust vent.
□ Dis	crowave/Convection Oven Identify and list the brand, model, type, and output wattage of the unit. hwasher - if installed Identify and list the brand, model, and type of unit.
In F	House Vacuum System – <i>if installed</i> Identify and list the brand, model and type of unit.
	ctric Fireplace – if installed Identify and list the brand, model and type of unit.
	ok Top Exhaust Fan Operate and verify condition of the exhaust function and fan speeds.
	ling Mounted Fans and Ceiling Exhaust Vents Operate and verify condition of the blade direction and fan speeds.
	erior Conditions and Appearance Visually inspect all ceilings, walls, interior doors, and flooring for signs of water intrusion, surface damage and/or staining.
1 1	Operate all interior, exterior and décor lighting – 12-volt and 120 volts

Cabinets and Closet Condition





Inspect and evaluate all cabinet doors, drawers, and pull-out operation.
 Furniture □ Visually inspect the condition of the dinette table/booth, chairs, recliners, and sofa. □ Visually inspect and note signs of mattress damage or staining.
Entertainment System ☐ Visually inspect and operate all TV and stereo equipment. ☐ Verify DVD/disc players and radios are operational.
Shower/Tub Enclosure ☐ Evaluate and rate the seals around the framework and doors for water leaks. ☐ Operate the door and latch system to verify its operation.
Motor Home - Please note the following items: Due to insurance issues the Motor Home can NOT be driven by the Inspector. Also, the lack of clearance under the motor home and safety issues the Inspector will conduct the following visual inspections from the outer perimeter of the motor home.
Chassis and Undercarriage Uisually inspect for rust, damage, and excessive oil on the underside of the motor home.
Steering Uisually inspect for bent or damaged components and hydraulic leaks.
Leveling System Uerify the system operates properly by extending and retracting leveling system.
Engine *strongly recommend performing oil analysis to determine internal combustion engine component condition. ☐ Make and model of the engine. ☐ Verify oil level on the dipstick. ☐ Indications of engine issues or any noises while running.
Radiator *strongly recommend performing coolant analysis to determine the condition of the coolant fluid and the internal cooling system. ☐ Visually inspect the coolant reservoir, radiator, and hoses.
Transmission *strongly recommend performing transmission fluid analysis to determine the condition of the fluid and the internal components of the transmission. □ Fluid level on dipstick. □ Indications of contaminated transmission fluid.
Running Gear (Motor Home) ☐ Type and number of axles. ☐ Inspect the frame, axles, springs, rims and other components for rust, oil stains and visible damage. ☐ Document the information on the tires as to their age, tire tread condition and weight capacities.





Hitch S	ystem	/Hook	Up
---------	-------	-------	----

☐ Inspect and identify the type of system used to tow vehicles.

Weight Labels and Data Plates

]	Identify	and	document the	Vehicle	Identification	Number	(VIN).
---	----------	-----	--------------	---------	----------------	--------	--------

- ☐ Locate and document Vehicle Frame Number.
- ☐ Document the License plate info.
- ☐ List the Inspection sticker information if applicable.
- ☐ List the RVIA inspection seal number.
- ☐ List the Gross Vehicle Weight Rating.
- ☐ List date of manufacturer.

