



Essential Inspection Points for Towable RVs (Travel Trailers and 5th Wheels)

We appreciate your business and look forward to providing you with the most advanced RV inspection available in today's RV market. So that we may provide you with a thorough inspection, your RV will need to be hooked up to all the utilities: fresh water, electricity, and sewer during the inspection.

Due to the nature of RV absorption refrigerators and the time it takes for these refrigerators to cool, the refrigerator must have been in operation for at least 12 hours before an accurate temperature reading can be taken in the freezer and the refrigerator compartments.

This report will consist of 25 to 30 photos describing the items that have been identified during the detailed **Essential Towable Inspection**.

Roc	Inspect and rate the overall Roof Condition. Rate the condition of the roof vents, air conditioners, antenna and other components that are mounted on the roof.
Sid □	ewall and End Caps Inspect and evaluate the appearance and functional condition of the sidewalls, entrance doors, windows, and cargo access doors.
	Inspect and rate the roof condition. Inspect and evaluate the condition of the seals, sweeps and gaskets for possible damage. Inings and Slide Out Toppers Operate and rate condition of the awning frames and latching mechanisms.
	Assis Turn Signal and Running Lights (12-volt DC) Operate and evaluate the emergency break away switch. Activate and evaluate the operation of the DOT lights mounted on the RV.
	Inspect and rate the condition of the power cord and its connection ends. Remove cover panel of 120-volt circuit breaker box to visually inspect the condition of the wiring, circuit breakers and grounding connections. Test and verify the output operation of the 120 VAC to 12 VDC converter for charging of the deep cycle batteries.
	nerator – if installed *strongly recommend performing oil analysis to determine internal combustion gine component condition. Identify and note the model, serial number and run hours of the generator. Check oil level.





	Start and operate the onboard generator.
	erter – if installed Identify and note the model and serial number of the inverter. Visually inspect the wiring and electrical connections and fuses/circuit breakers.
	ach Battery System – (12-volt DC deep cycle Battery Electrical System) Evaluate the condition, age, and matched sizing of the battery stack. Access and visually inspect the wiring, fuse panel and fuses of the 12-volt DC electrical system.
	sh Water System Verify the fresh water connections for the City Water hookup are operational. Verify the onboard fresh water tank and pressure pump system will operate and maintain pressure.
	Operationally test and inspect both waste (gray and black) plumbing systems for leaks under the sinks, shower, around the toilet and discharge lines. Operate both drain valves and test for ease of operation. Verify the drain cap is in place and will hold waste water.
Life	e Safety Items Perform and document LP gas timed leak test at cook top burner spud for 5 minutes at 8 inches of water column gas pressure.
	Test the Ground Fault Circuit Interrupter (GFCI) circuits in the 6-foot range of the water areas of the bathroom, kitchen and exterior receptacles. Test all wall receptacles for correct polarity and ground fault. Test the exterior skin for Hot Skin that would cause electrical shock. Emergency Exit Windows – Verify all safety windows are operational. Fire Extinguisher – Verify unit is secure in bracket and dial indicates extinguisher is fully charged. Smoke/Fire Detector –Test and verify operation of units. Carbon Monoxide Detector (if applicable) – Test and verify operation of unit. LP Gas Detector – Verify gas detection and audio alarm. Document expiration date of detector. Verify the rubber grommet is properly sealed around LP gas line of water heater.
	Gas System Visually inspect all hoses and pressure regulators for damage and age deterioration. Verify plastic cover has been installed over regulator.
	T Cylinders - if equipped Document the manufacturer dates of DOT cylinders. List the tank sizes that have been installed. Conduct visual inspection of exterior of cylinder for rust and other damage.
	ME tank - <i>if equipped</i> If tank is visible, conduct a visual inspection of tank for rust or physical damage.

Refrigerator





Operate on all heat sources - 120-volt AC, LP gas and for 3-way refrigerators, 12-volt DC. Collect serial and model number and verify with manufacturer if recall notice has been issued and completed for this unit.
Iter Heater Identify the brand, model, and type of water heater. Fill tank with water (if necessary) and verify operation on all heat sources – LP gas and 120-volt AC if equipped with heating element.
rnace Operate and verify warm air discharge out of vents and proper return air flow to unit.
ok Top/ Stove Verify the ignition and operation of all top burners and the oven flame (if equipped).
Conditioner(s) Perform cooling efficiency test (Delta T) on each unit.
Visually inspect and verify a wash and rinse cycle of the washer and dryer. Evaluate and rate the exterior condition of the dryer exhaust vent.
crowave/Convection Oven Identify and list the brand, model, type, and output wattage of the unit.
hwasher - <i>if installed</i> Identify and list the brand, model, and type of unit.
House Vacuum System – if installed Identify and list the brand, model, and type of unit.
ctric Fireplace – if installed Identify and list the brand, model, and type of unit.
ok Top Exhaust Fan Operate and verify condition of the exhaust function and fan speeds.
ling Mounted Fans and Ceiling Exhaust Vents Operate and verify condition of the blade direction and fan speeds.
erior Conditions and Appearance Visually inspect all ceilings, walls, interior doors and flooring for signs of water intrusion, surface damage and/or staining. Operate all interior, exterior and décor lighting – 12-volt and 120-volt.

Cabinets and Closet Condition





	Inspect and evaluate all cabinet doors, drawers, and pull-out operation.
	rniture Visually inspect the condition of the dinette table/booth, chairs, recliners, and sofa. Visually inspect and note signs of mattress damage or staining.
	tertainment System Visually inspect and operate all TV and stereo equipment. Verify DVD/disc players and radios are operational.
□ □ Ru	Evaluate and rate the seals around the frame work and doors for water leaks. Operate the door and latch system to verify its operation. Inning Gear (Towable) Type and number of axles. Inspect the frame, axles, springs, rims and other components for rust, oil stains and visible damage Document the information on the tires as to their age and weight capacities.
Hit	ch <mark>System/Hook Up</mark>
	Inspect and identify the type of system used to tow vehicle.
Lev	veling System
	Operate by extending and retracting system.
We	eight Labels and Data Plates Identify and document the Vehicle Identification Number (VIN). Document the License plate info.
	List the Inspection sticker information – if applicable.
	List the RVIA inspection seal number.
	List the Gross Vehicle Weight Rating.